


Mirror Models 35851 US Military Bulldozer





Assembly instructions







Go through assembly guide before you start your work. We recommend to use a sharp scalpel to remove parts carefully.

Heat up PE parts with lighter before use, brass will soften and become easy to bend and work with **Tamiya Super Thin Glue** recommended for plastic parts, let the glue work for a few seconds, then push parts together, melted plastic will fill the gaps between parts. You can also melt sprue frame and use it as an amazing filler for small works, or use this glue to wash out tiny seam lines on little parts or make texture on some parts etc.



You might need to adjust some holes with drilling bits





















push 134 into 136 and 135 as deep as it goes






glue 135 into 125 as deep as it goes!






0,5mm wire can be used to make pipes




116






assemble 108 before 48 joint dries totally, you might need to adjust its position to go through opening in 108


Make two, left and right



use Tamiya Super Thin glue to melt plastic properly and push 87 (94) well into 72 and 74 (73 and 75) Melted plastic will fill nicely possible gaps




metal springs
sand off the ends flat, length 19mm








springs may not be used if you use bogie safety covers, when springs are not visible

A12


Assemble metal springs between A16 and A19,






6





You can replace plastic floor with PE part, and optionally keep front vertical covers and foot rests marked, and assemble them to PE floor. Get carefully tiny levers through holes, openings and slots





PE7 optional




arm's rests PE8 and A13 can be assembled inside or outside the seat














do not assemble lights for bulldozer model





Mind correct direction of tracks! Track links are workable, however it is recommended to assemble them in short sections around, leaving the top for the end, and secure them with glue






10





pre-bend PE a, b, c, d as shown below, then pull them around parts 57, insert parts 45 and complete each. Secure pulleys with C/A glue, but PE housings should rotate around pins 57







PEb







PEa





PEc

PEd







remove two large nut heads






do not glue 11 and 12 into holes in 16 until whole structure is fitted to tractor later




drill holes 0,9mm




front pulley





back pulley






PE guard




blade pulley




do not glue until you have set angle with ropes to upper pulley according to blade lift



front rope assembly




back towing rope assembly




back blade lifting rope assembly




Additional equipment, earth scrapper, resin figures and more will be available soon at: www.LZmodels.com
 If you have experienced missing or damaged part, contact us directly for replacement at info@mirror-models.com
 You can download up to date Hi-Res instructions in PDF and detailed part list at
<http://www.mirror-models.com/135-US-Military-Bulldozer.html>
 You are welcome to join our contest "The Best US Military Tractor Build" and win some amazing prize. More details will show up soon at our website: <http://www.mirror-models.com>




1x




1x




1x




1x




5x




2x



2x




1x




1x


2 clear parts,
 wire 0,5mm,
 scale rope,
 2 metal springs,
 PE detail set,
 decal sheet



1x




5x




1x

1x



2x

2x



2 clear parts, wire 0,5mm, PE detail set, decal sheet

